PACKMOJO

DIELINE ORIENTATION GUIDE

PAPER BAGS

Paper bags are made of a sheet of paperboard and three pieces of reinforcing paperboard for the base and the panels where the handles are attached. Paper bags comes with rope handles, ribbon handles or twisted paper handles. There are two common styles for the bottom.



BASE BOARD
(LEAVE BLANK)



RIGHT HANDLE REINFORCING BOARD
(LEAVE BLANK)

LEFT HANDLE REINFORCING BOARD
(LEAVE BLANK)

BOTTOM OPTION 1

PAPER BAG PAPERBOARD
(OUTSIDE ARTWORK)



Note: Yellow lines indicate fold lines when packed flat. They will not be folded when in use.

BOTTOM OPTION 2

PAPER BAG PAPERBOARD
(OUTSIDE ARTWORK)



FOR MORE PACKAGING DESIGN TIPS, VISIT PACKMOJO.COM/DIELINE-DESIGN-TIPS/